


# ALEKO®


## ALEKO 5x5x4 Square Dog Kennel Assembly Instructions

5ft.(L) x 5ft.(W) x 4ft.(H)




[www.AlekoGates.com](http://www.AlekoGates.com)


# Components



Gate Panel



Plain Panels 7 pcs.



Clamps 16 pcs.



Assembly Instructions

## Tools Needed


- ½ inch wrench
- Wire cutters

**Kennel assembles easily in less than one hour.**

## Step 1 Determine Position of Gate Panel

# 1

Gate panel can be positioned on right or left side of kennel. For ease of use, it is recommended that the gate panel be positioned on the right side ( 1A ).




## Step 2 Assemble Kennel

# 2


**Important: Please assemble the panels as noted in illustration (2A).**

1. Using a wrench, remove the two kennel clamps that are attached to the wire mesh of each of the kennel panels ( 2B ).
2. Using a wrench and two of the supplied kennel clamps, attach a plain panel to the gate panel. Position one clamp approximately 4 inches from the top of the kennel and one clamp approximately 6 inches from the bottom of the kennel. For the safety of your dog, attach clamp so that nut is on the outside of the kennel. See ( 2C ) for clamp and panel orientation.
3. Continue connecting remaining plain panels using wrench and two clamps per connection.


2A



2B



2C



Note: Kennel can be locked

**Expand your kennel by purchasing additional panels**